


28 656 000 RELEXA PLUS 80 TOP 4 DUSJGARNITYR 4 SPRAYER




RESERVEDELER , juni 2007 – now

- 1: Koblingsstykke (Spare part-nr. 28635XX0)
- 1.1: Sealing washer Ø 11 x Ø 2 (Spare part-nr. 0122400M)
- 2: Sil (Spare part-nr. 0700200M)
- 3: Hånddusjholder/glideelement (Spare part-nr. 45650IP0)
- 3.1: Dekkplate (Spare part-nr. 45652P00)
- 4: Holder for dusjstang (Spare part-nr. 45651IP0)
- 4.1: Dekkplate (Spare part-nr. 45652P00)
- 5: Dekkplate (Spare part-nr. 45652P00)
- 6: Replacement pulsator element (Spare part-nr. 45656XX0)
- 7: Demonteringsnøkkel (Spare part-nr. 45654000)*

* Optional accessories

28 656 000 RELEXA PLUS 80 TOP 4 DUSJGARNITYR 4 SPRAYER



RESERVEDELER , januar 1993 – juni 2007

- 1: Hånddusj 4 sprayer (Spare part-nr. 28178000)
- 1.1: Replacement pulsator element (Spare part-nr. 45656XX0)
- 1.2: Koblingsstykke (Spare part-nr. 28635XX0)
- 1.3: Sil (Spare part-nr. 0700200M)
- 1.4: Demonteringsnøkkel (Spare part-nr. 45654000)*
- 2: Dusjstang, 600 mm (Spare part-nr. 28620000)
- 2.1: Hånddusjholder/glideelement (Spare part-nr. 45650IP0)
- 2.1.1: Dekkplate (Spare part-nr. 45652P00)
- 2.2: Holder for dusjstang (Spare part-nr. 45196IP0)
- 2.2.1: Dekkplate (Spare part-nr. 45652P00)
- 2.3: Utligningsskive (Spare part-nr. 45459000)*
- 3: Såpeskål (Spare part-nr. 28631000)
- 3.1: Dekkplate (Spare part-nr. 45652P00)
- 4: Dusjslange (Spare part-nr. 28151000)
- 5: Utligningsskive (Spare part-nr. 45459000)*

* Optional accessories